

Setting application for DCC0241X instruction manual

Table of contents


1.	Introduction.....	- 3 -
1 - 1.	Overview	- 3 -
2.	Menu screen	- 4 -
2 - 1.	Display details	- 5 -
3.	CH setting screen.....	- 6 -
3 - 1.	Display details	- 7 -
4.	CH PATTERN setting screen.....	- 8 -
4 - 1.	Display details	- 9 -
4 - 2.	CH PATTERN registration method	- 10 -
5.	COMMON setting screen.....	- 11 -
5 - 1.	Display details	- 12 -
5 - 2.	Display of setting items based on the controller version.....	- 13 -
6.	Application setting screen.....	- 14 -
6 - 1.	Display details	- 15 -

1. Introduction

1 - 1. Overview

The setting application for DCC0241X is an application for Windows OS that allows you to set up the controller DCC0241X-AZ (hereinafter referred to as “controller”) via serial communication (RS-232C).

Besides setting, setting data can be saved / read and settings can be retrieved from the controller.




2. Menu screen

This is the first screen displayed when the application is launched.


Move to each screen from this screen.

You can also perform the following operations.

- Create new setting data
- Read setting data file
- Save setting data file
- Retrieve setting data from the controller



2 - 1 . Display details



No.	Name	Details
①	New File	Create new data (default value).
②	Open File	Read the setting data from the file.
③	Save All	Save the setting data to a file.
④	Application Settings	Move to the application setting screen.
⑤	CH SETTING	Move to CH setting screen.
⑥	CH PATTERN SETTING	Move to CH pattern setting screen.
⑦	COMMON SETTING	<p>Move to COMMON setting screen.</p> <p>Click to view the screen below.</p> <p><u>* When clicked, common settings can be made even if the version information cannot be confirmed (controller and PC are not connected).</u></p> <div><div>Checking the version...</div><div>⇒</div><div></div></div>
⑧	Read Settings from Controller	<p>Read the setting data from the file.</p> <div><div>Checking the version...</div><div>⇒</div><div><div>Reading from controller...</div><div>CH Setting Reading 115/781</div></div></div>

3. CH setting screen

This screen sets the screw fastening conditions for each channel and sends them to the controller. Select the channel you want to set from the list on the left, and set the screw fastening conditions in the CH-specific setting column.

Setting application for DCC0241X New setting data

CH SETTING

MEASUREMENT

TIME

SIGNAL

CH SELECT

CH1

CH2

CH3

CH4

CH5

CH6

CH7

CH8

ALL CH WRITE

CH1 SETTINGS

NAME

1	Fastening Type	<div><div>SOFT</div><div>HARD</div></div>
2	Count	<div>4</div>

| 3 | Speed | Lv5 |


| 4 | Torque | 10 % |


| 5 | First Speed | OFF |

| 6 | First Speed Time | --- |

WRITE

3 - 1 . Display details



No.	Name	Details
①	Back to Menu	Return to the menu screen.
②	Save File	Save configuration data to a file. If the setting is changed, the icon will change color to call attention. 
③	MEASUREMENT	Select the method for measuring the set time such as First speed and second speed.
④	CH SELECT	Displays a list of channels. Select the channel you want to set.
⑤	CH SETTINGS	Set the CH name and screw fastening conditions for the selected channel. The changed settings are displayed in bold font. If you move the pointer over the setting item name, an explanation will be displayed. <div> <div>2</div> <div>Count</div> <div>4</div> </div> <div> <div>3</div> <div>Speed</div> <div>Lv5</div> </div>
⑥	ALL CH WRITE	Write the setting data of all channels to the controller. The following screen is displayed during communication. <div> <div>Checking the version...</div> <div>→</div> <div> Writing to Controller... <div>CH Setting Writing 62/781</div> </div> </div>
⑦	WRITE	Sends the selected channel setting data to the controller. The following screen is displayed during communication. <div> <div>Checking the version...</div> <div>→</div> <div> Writing to Controller... <div>CH Setting Writing 8/27</div> </div> </div>

4. CH PATTERN setting screen

This is the screen to set each channel pattern (register channel combination) and send it to the controller.

Select the channel pattern you want to set from the list on the left, and set it in the CH pattern setting field.

Setting application for DCC0241X New setting data

CH PATTERN SETTING

CH PATTERN SELECT

- CH PATTERN1
- CH PATTERN2
- CH PATTERN3
- CH PATTERN4
- CH PATTERN5
- CH PATTERN6
- CH PATTERN7
- CH PATTERN8
- CH PATTERN9

ALL Pat. WRITE


CH PATTERN1 SETTING





NAME: Move to: **LOOP**

1	CH1	CH1	CH2	CH3	CH4	CH5
2		CH6	CH7	CH8	CH9	CH10
3		CH11	CH12	CH13	CH14	CH15
4		CH16	CH17	CH18	CH19	CH20
5		CH21	CH22	CH23	CH24	CH25
6		CH26	CH27	CH28	CH29	CH30
7						
8						

WRITE



4 - 1 . Display details



No.	Name	Details
①	Back to Menu	Return to the menu screen.
②	Save File	Save configuration data to a file. If the setting is changed, the icon will change color to call attention. 
③	CH PATTERN SELECT	A list of CH PATTERNS is displayed. Select the channel pattern you want to set.
④	CH PATTERN SETTINGS	Set the CH PATTERN name and channel registration of the selected channel pattern and the destination to move to after completion. If you move the pointer over a channel, the channel settings will be displayed.  * Registration of No. 1 is mandatory.
⑤	ALL Pat. WRITE	The setting data of all CH PATTERN are sent to the controller. The following screen is displayed during communication. 
⑥	WRITE	The selected setting data of CH PATTERN are sent to the controller. The following screen is displayed during communication. 

4 - 2 . CH PATTERN registration method


To register a CH PATTERN, select the channel to register in the channel list on the right and add it to the columns No.1 to No.8 on the left by clicking Add button or by drag-and-drop operation.



Channel registrations cannot be made after a blank.
It is automatically registered without blank.

Use the up and down buttons to change the order of the registered channels.

If you want to delete, use the delete button.



5. COMMON setting screen

This screen is used to make common controller settings and send them to the controller


Setting application for DCC0241X New setting data


COMMON SETTING

CH Change Type	<div>CH PATTERN</div>	<div>INPUT</div>
Check Buzzer	<div>OFF</div>	<div>ON</div>
Buzzer Volume	<div>100%</div>	
Fastening NG Check	<div>OFF</div>	<div>ON</div>
LCD Backlight	<div>OFF</div>	<div>ON</div>
Manual Mode	<div>OFF</div>	<div>ON</div>
Reset Mode	<div>Both</div>	
Caution mode	<div>OFF</div>	
Torque Check Mode	<div>OFF</div>	<div>ON</div>
Idling NG time	<div>OFF</div>	
Forced stop	<div>OFF</div>	

WRITE

5 - 1 . Display details



No.	Name	Details
①	Back to Menu	Return to the menu screen.
②	Save File	Save configuration data to a file. If the setting is changed, the icon will change color to call attention. 
③	COMMON SETTING	Make common settings for the controller. The changed settings are displayed in bold font. If you move the pointer over the setting item name, an explanation will be displayed.
④	WRITE	Send common setting data to the controller. The following screen is displayed during communication. <div> <div>Checking the version...</div> <div> <div>Writing to Contoroller...</div> <div>Common Setting Writing 6/11</div> </div> </div>

5 - 2 . Display of setting items based on the controller version

Depending on the controller version, it may not be possible to set some items. The items that cannot be set are grayed out and cannot be operated.

Locations that cannot be set are grayed out.


1.10 or earlier (Forced stop not supported)	Forced stop	OFF
1.20 or later (Forced stop supported)	Forced stop	OFF

* If you continue setting a controller with a different version, return to “2. Menu screen.”


6. Application setting screen

This screen is used to set communication settings with the controller and language settings.

Setting application for DCC0241X New setting data



Application Settings



COMMUNICATION SETTINGS

Port

COM1

Baud Rate

38400 bps

Data Bits


8 bit

Parity

None

Stop Bits


1 bit



LANGUAGE SETTING

Language

English




VERSION INFORMATION

Application	Version	Ver 2.0.0.0
Controller	Model	DCC0241X-AZ
	Version	Ver 1.20
Screwdriver	Model	DLV45C
	Version	Ver 1.01

- 14 -

6- 1 . Display details



No.	Name	Details
①	Back to Menu	Return to the menu screen.
②	COMMUNICATION SETTINGS	Set the communication with the controller (RS-232C). * Do not change the port other than the communication port except in special cases
③	Register COMMUNICATION SETTINGS	Save the communication settings. If you change the setting, the icon will change color to alert you.
④	LANGUAGE SETTING	Set the display language for Japanese / English.
⑤	Register LANGUAGE SETTING	Save the language settings. If the setting is changed, the icon will change color to call attention.
⑥	VERSION INFORMATION	Displays the version of this application.